

| С                                        | atego                        | orizing Work S                                                                                                             | pad     | ce                                 |
|------------------------------------------|------------------------------|----------------------------------------------------------------------------------------------------------------------------|---------|------------------------------------|
|                                          | Restricted e<br>ed for conti |                                                                                                                            | confine | d Space                            |
| Permit-<br>Required<br>Confined<br>Space | YES                          | Hazardous<br>Atmosphege<br>Engulfment<br>Hazard Or<br>Configuration Hazard<br>Or<br>Any other recognized<br>serious hazard | NO      | Non<br>Permit<br>Required<br>Space |




## <section-header><list-item><list-item><list-item><list-item><list-item>




Developed under an OSHA Susan B. Harwood Grant, #46F4-HT01, by the Associated Builders and Contractors-Central Texas Chapter

4





















































































## Engineered Systems

- In some cases, normal protection methods will not work
- · In those cases, a Registered Professional Engineer must be consulted for guidance





